




Baridi 47cm 60/40 Fridge Freezer, 157L Capacity Low Frost White-DH252/Black - DH253



Models: DH252, DH253

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to
instructions



Indoor use
only



Warning:
flammable
material

SAFETY

• ELECTRICAL SAFETY

- **WARNING!** It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Dellonda recommend that an **RCD** (Residual Current Device) is used with all electrical products.
- Electrical safety information: It is important that the following information is read and understood.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.
- **Important:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.
- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- **DO NOT** use with an extension cord.
- Ensure that any faulty item is repaired or replaced immediately by a qualified electrician.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- Ensure that repairs are carried out by a qualified electrician.
- This product is not designed to be used with an inverter.

• GENERAL SAFETY

- **WARNING!** When positioning the appliance, ensure the supply cord is not trapped or damaged. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- **DO NOT** use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **DO NOT** damage the refrigerant circuit.
- **DO NOT** use electrical appliances inside the storage compartment of the appliance i.e. hair dryers, heater elements etc.
- **DO NOT** store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- **DO NOT** remove items from the fridge freezer compartment if your hands are damp/wet, as this could cause skin abrasions or Frost/Fridge freezer burns.
- **WARNING! DO NOT** locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.
- Children from age 8 years and above, persons with reduced physical, sensory, or mental capabilities those with lack of experience and knowledge can use the appliance, if they have been given supervision or instruction concerning use of the appliance in a safe way to understand the hazards involved.
- Children shall **NOT** play with the appliance.
- Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
- To avoid contamination of foodstuffs, please respect the following instructions:
 - Opening the door for long periods can cause a significant increase of the temperature in the compartment of the appliance.
 - Clean regularly surfaces that can come in contact with drink and accessible drainage systems.
- If the appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the lid ajar to prevent mould developing within the appliance.
- This refrigerant appliance is intended to be used at ambient temperatures ranging from 16°C to 38°C.
- This refrigeration appliance is not intended to be used as a built-in appliance.
- **WARNING!**

DISPOSAL

- Refrigerant and cyclopentane foaming material used for the refrigerator are flammable. Therefore, when the fridge freezer is scrapped, it shall be kept away from any fire source and be recovered by a recovering company with corresponding qualifications, this will prevent damage to the environment or any other harm. When the refrigerator is scrapped, disassemble the doors, and remove door gasket's and shelves; so as to prevent trapping children inside the fridge freezer.




Fire rating plate

SPECIFICATION

MODEL NO:	DH252	DH253
Capacity	157L (109L Fridge, 48L Freezer)	157L (109L Fridge, 48L Freezer)
Climate Class	N/ST	N/ST
Colour	White	Black
Defrost Method	Manual	Manual
Door type	Reversible	Reversible
Energy Efficiency Class	E	E
Foaming Gas	Cyclopentane	Cyclopentane
Fuse Rating	13A	13A
Internal Dimensions (W x D x H)	Fridge (W x D x H): 405 x 379 x 708mm Freezer (W x D x H): 359 x 360 x 505mm	Fridge (W x D x H): 405 x 379 x 708mm Freezer (W x D x H): 359 x 360 x 505mm
Number of Shelves	3 Shelves (Fridge), 3 Drawers (Freezer)	3 Shelves (Fridge), 3 Drawers (Freezer)
Nett Weight	34kg	34kg
Operating Sound Level:	39dB	39dB
Plug Type	3-Pin BS	3-Pin BS
Power Cable Length	1.8m	1.8m
Rated current	0.5A	0.5A
Refrigerant	R600a (43g)	R600a (43g)
Star Rating	4	4
Voltage/Frequency	220-240V/50Hz	220-240V/50Hz
Temperature Range	Fridge: -3 - 10°C Freezer: -10 - -24°C	Fridge: -3 - 10°C Freezer: -10 - -24°C

PRODUCT FEATURES


No	Description
1	Thermostat
2	Fridge glass shelf
3	Tray cover
4	Fruit and veg tray
5	Freezer draws
6	Levelling feet
7	Bottle racks




PREPARATION

DOOR REVERSAL INSTRUCTIONS


1. Remove the hinge cover and upper hinge from the top right of the cabinet. Remove the screw hole cover from the top left side of the cabinet.




3. Remove the centre hinge from the right side cabinet. Remove the screw hole covers from the left side of the cabinet.




5. Remove the door stop from the lower right side of the door, and install the door stop on the lower left side of the door.




7. Install the fridge freezer door. Install the centre hinge on the left side of the cabinet. Install the screw hole covers on the right side of the cabinet.




2. Remove the door from the cabinet. Move the hinge plug from side the top left to the top right side of the door the top left to the top right side of the door.




4. Remove the door from the cabinet. Move the hinge plug from the top left to the top right side of the door.



6. Remove the lower hinge from the bottom right side of the cabinet. Remove both adjustable feet. Remove the lower hinge pin from the hinge, flip the hinge over and reinstall the hinge pin on the other side. Install the lower hinge on the bottom left side of the cabinet. Install both adjustable feet.



8. Install the refrigerator door. Install the upper hinge and the hinge cover on the top left side of the cabinet. Install the screw hole cover on the top right side of the cabinet.



INSTALLATION LOCATION

• VENTILATION CONDITIONS

- 1. The position you select for the fridge freezer installation should be well-ventilated and cool. Do not locate the fridge freezer near a heat source such as cooker, and avoid it from direct sunlight, thus guaranteeing the refrigeration effect while saving energy consumption. **DO NOT** locate the fridge freezer in the damp place, so as to prevent the fridge freezer from rusting. The quantity of the refrigerant gas of the fridge freezer being divided by the total space of the room in which the fridge freezer is installed should be less than 8g/m³.
- **Note:** The amount of refrigerant gas for the fridge freezer can be found on the serial plate.
- 2. Allow at least 30mm of free space for the top of the unit, at least 100mm for both sides of the unit and at least 50mm for the rear of the unit.

W	D	H	A	B	C (°)	E	F	
474	495	1440	792	923	130+5	50	100	DH252 DH253

- **NOTE:** Figures on the right of page illustrate the space demand of the product.

• LEVEL GROUND

- Place the fridge freezer on the solid and flat ground (floor) to keep it stable, or else, it will vibrate and be noisy. When the fridge freezer is placed on materials such as carpet, straw mat, polyvinyl chloride, solid backing plates should be fitted underneath the unit to prevent damage to the flooring.

- **NOTE:** Unobstructed ventilation shall be maintained around the appliance or in an embedded structure.


• PREPARATIONS FOR USE

• 1. STANDING TIME:

- After the fridge freezer is properly installed and well cleaned, do not switch it on immediately. Leave the fridge freezer to stand for more than 4 hours to allow gases to settle, thus ensuring its normal operation.

• 2. CLEANING

- Wipe the inside of the fridge freezer with a soft cloth.



- **3. POWER-ON**

- Insert the plug into the mains socket to start the compressor. After 1 hour, open the fridge freezer door, if the temperature inside the fridge freezer compartment drops, it indicates the refrigeration system is working normally.

- **4. STORAGE OF FOOD**


- After the fridge freezer runs for a period of time, the internal temperature of the fridge freezer will be automatically controlled according to the user's temperature setting. After the fridge freezer is fully cooled, put in your food, which usually needs 2~3 hours to be fully cooled. In summer, when the temperature is high, it takes more than 4 hours for the foods to be fully cooled (keep the opening of the fridge freezer door to a minimum to avoid internal temperature drop).

- **NOTE:** If the fridge freezer is installed in a place with moisture, make sure to check the circuit breaker operation. If vibration and noises are produced due to the fridge freezer contacting the wall or if the wall gets blackened by air convection around the compressor, move the fridge freezer away from the wall. Setting up the fridge freezer may cause noise or image disturbance on your mobile phone, fixed-line telephone, radio receiver, television surrounding it, so try to keep the fridge freezer as far away from these items as possible.

- **PRE CHECKS**

- 1. Clean the fridge freezer with lukewarm water and detergent and wipe dry.
- **NOTE:** Electrical components should be cleaned with a dry cloth.
- 2. Turn the thermostat knob to the "2" position, and plug the fridge freezer into the wall outlet. The compressor will begin to run.
- 3. Check, after 30 minutes of operation, to ensure that the fridge freezer is cold.

OPERATION



- **TEMPERATURE CONTROL**

- The temperature of the appliance can be adjusted by turning the temperature control switch. The thermostat can be set between 1 and 7.
- 1 is the warmest setting.
- 7 is the coldest setting.
- Set the dial to **OFF** to turn off the cooling function.
- Under the normal operating condition (in spring and autumn), it is recommended to set the temperature at 4.
- In summer when the ambient temperature is high, it is recommended to set temperature between 3-4, so as to guarantee the fridge and freezer temperatures remain constant and reduce the refrigerator continuous running time. In winter when the ambient temperature is low, it is recommended to set temperature between 5-6 to avoid frequent start/stop of the refrigerator.
- **NOTE:** The temperature requirement may vary in accordance with the outside conditions.

- **FAST FREEZE**

- 1. Fast freezing makes water in the food form into fine ice crystal, so as to prevent the cell membrane from being damaged and the cytoplasm from being lost when thawing, thus preserving the original freshness and nutrition of food.
- 2. Fresh food and fish to be preserved for a long time should be frozen in a fast manner. To select fast freezing, adjust the knob switch to mode "7" before adding the food.
- 3. After fast freezing, turn the knob back to its original mode (In general, the fast freezing time shall not exceed 4 hours).
- **NOTE:** The control switch setting of '6' or '7' is suitable when ambient temperature is under 16 °C. It may lead to ice formation if the refrigerator keeps running at such setting for a long time under the normal ambient temperature. In which case, it is recommended to adjust back the there.

- **TIPS FOR SHOPPING THE FROZEN FOODS**

- **PRECAUTIONS**

- The appliance might not operate consistently (there is possibility of defrosting or temperature becoming too warm in the frozen food compartment, when sited for an extended period of time below the cold limit of the temperature range for which the refrigerating appliance is designed).
- The information of climate type of the appliance is provided on the rating plate.
- The internal temperature could be affected by such factors as the location of refrigerating appliance, ambient temperature, and frequency of times the door remains open etc, and if appropriate, a warning that setting of any temperature control device might have to be varied to allow for these factors should be made.
- Effervescent drinks should not be stored in the freezer compartment or the low-temperature compartment.

- **FOOD STORAGE LOCATION**

- Due to the cold air circulation in the refrigerator, the temperature of each area in the refrigerator is different, so different kinds of food should be placed in different areas.
- The fresh food compartment is suitable for the storage of such foods as need not to be frozen, e.g. cooked food, beer, eggs, some condiments that need cold preservation, milk, fruit juice, etc. The fruit and veg tray is suitable for those that don't need to be frozen.
- The freezer compartment is suitable for the storage of ice cream, frozen food and the foods to be preserved for a long time.

- **USE OF THE FRESH FOOD COMPARTMENT**

- **FRIDGE SHELF** When removing the shelf, lift it up first, and then pull it out; and when installing the shelf, place it into position before putting it down. (For the two-section shelf, push the first section to the rear end, and then pull the second section out). Keep the shelf rear flange upward, to prevent foods from contact the liner wall. When taking out or putting in the shelf, hold it firmly, and handle with care to avoid damage.

- **FRUIT AND VEG TRAY:** Pull out the fruit and veg tray for access to food. After using or cleaning the cover plate of the fruit and veg tray, be sure to put it back onto the fruit and veg tray, so that the internal temperature of the fruit and veg tray will not be affected.

- **HOW TO USE THE ICE-MAKING BOX**

- Place the ice-making box in the upper position of the fridge freezer compartment, so that it ices up as soon as possible.

- **FOOD STORAGE**

- Rinse the food and wipe dry before storing them inside the refrigerator.
- Before foods are put in the refrigerator, it is advisable to put them into plastic resealable bags, so as to prevent water evaporation to keep fresh and prevent taint or odour.
- **DO NOT** store excessive or overweight foods, to avoid the shelf from being crushed. When storing the foods, keep a distance away from the inner wall; and **DO NOT** place the water-rich foods too close to the fridge rear wall, lest they get frozen to it.

- **STORAGE OF FOODS**

- Foods should be stored by category, with the foods you eat every day placed in front of the shelf, so that the door open duration can be shortened.

- **ENERGY-SAVING TIPS**

- Allow the hot food cool down to the room temperature before putting it in the refrigerator. Put the frozen food in the fresh food compartment to thaw, using the low temperature of the frozen food to cool the fresh food, thus saving energy.

- **STORAGE OF FRUITS AND VEGETABLES**

- **USE OF THE FROZEN FOOD STORAGE COMPARTMENT**

- The freezer temperature is controlled below -18 °C, and it is advisable to store the food for long-term preservation in the freezer compartment, but the storage duration indicated on the food packaging should be adhered to.
- The freezer drawers are used to store food that needs to be frozen. Fish and meat of large block size should be cut into small pieces and packed into fresh-keeping bags before they are evenly distributed inside the freezer drawers.
- Allow the hot foods to cool down to the room temperature before putting them in the freezer compartment.
- **DO NOT** put a glass container with liquid or the canned liquid that is sealed in the freezer compartment, so as to avoid bursting due to volume expansion after the liquid gets frozen.
- Divide the food into appropriately small portions
- pack the food up before freezing it, and the packing bag used should be dry, in-case the packing bags get frozen together. Foods should be packed or covered by suitable materials. This will keep the food firm, retain taste, and pollution-free, to avoid cross-contamination and transfer of odour.

- **TIPS FOR BUYING FROZEN FOODS**

- 1. When buying frozen food, look at the Storage Guidelines on the packaging. Store each item of frozen food for the period shown against the star rating. This is usually the period stated as “Best before date”, found on the front of the packaging.
- 2. Check the temperature of the frozen food cabinet in the shop where you buy the frozen foods.
- 3. Make sure the frozen food package is in perfect condition.
- 4. Always buy frozen products last on your shopping trip or visit to the supermarket.
- 5. Try to keep frozen food together whilst shopping and on the journey home, as this will help to keep the food cooler.
- 6. Don't buy frozen food unless you can freeze it straight away. Special insulated bags can be bought from most supermarkets and hardware shops. These keep the frozen foods cold longer.
- 7. For some foods, thawing before cooking is unnecessary. Vegetables and pasta can be added directly to boiling water or steam cooked. Frozen sauces and soups can be put into a saucepan and heated gently until thawed.
- 8. Use quality food and handle it as little as possible. When foods are frozen in small quantities, it will take less than for them to freeze up and thaw.
- 9. Estimate the amount of foods to be frozen. When freezing large amounts of fresh food, adjust the temperature control knob to the low mode, so, foods can be frozen up in fast manner, with the food freshness kept.

- **LOCATION**

- **DO NOT** place your fridge freezer near a heat source, e.g. cooker, boiler or radiator. Avoid from direct sunlight in out-buildings or sun lounges.

- **MAINTENANCE AND CLEANING**

INTERNAL CLEANING AND EXTERNAL CLEANING

- **WARNING!** Before cleaning, disconnect from mains supply. **DO NOT** plug in or plug out the plug with wet hands, because there is a risk of electric shock and injury.
- Cleaning and user maintenance on the appliance shall not be made by children without supervision.
- Place suitable water container under the drain cover in the lower left corner of the front panel, remove the drain cover, withdraw the drain body and rotate it such that the drain hole is placed above the water container.
- Reverse the procedure when operation is complete.
- **DO NOT** spill water directly on the fridge freezer, to avoid rust, electricity shock and accidents. **DO NOT** place your hands under the bottom of the fridge freezer, since you might get scratched by sharp metal corners.
- The food residuals in the fridge freezer are liable to produce bad odour, so the fridge freezer must be cleaned regularly.
- Remove all shelves, crisper box, bottle racks, cover board, and drawers etc., and clean them with a soft towel or sponge dipped in warm water or neutral detergent.
- Clear off the dust accumulated on the rear panel and side plates of the fridge freezer on a regular basis.
- After using detergent, be sure to rinse it with clean water, and then wipe it dry.
- **DO NOT** use a bristle brush, steel wire brush, detergent, soap powder, alkaline detergent, benzene, petrol, acid, hot water and other corrosive or soluble items to cleanse the cabinet surface, door gasket, plastic decorative parts, etc, so as to avoid damage.
- Carefully wipe dry the door gasket, clean the groove using a wooden implement wrapped with cotton. After the cleaning, fix the four corners of the door gasket first, and then embed it segment by segment into the door groove.
- **INTERRUPTION OF POWER SUPPLY OR FAILURE OF THE REFRIGERATING SYSTEM**
- In the event of an extended non-running of the refrigerating appliance (such as interruption of power supply or failure of the refrigerating system), to help prevent food spoilage try to open the fridge freezer door as less as possible. In this way can food safely and freshly kept for hours even in summer.
- **IF YOU GET THE POWER OUTAGE NOTICE IN ADVANCE:**
- 1. Adjust the thermostat knob to the high mode an hour in advance, so that food gets fully frozen (Do not store new food during this time). Restore the temperature mode to the original setting when power supply becomes normal in a timely manner.
- 2. You can also make ice with a watertight container, and put it in the upper part of the fridge freezer, so as to extend the time for fresh food to be stored.
- **NOTE:** Continuously use your fridge freezer so as not to affect the serviceable life.
- **DEFROSTING**
- After a period of use, a thin layer of frost will be formed on the fridge freezer compartment inner wall (or evaporator) surface, which may affect the refrigeration effect if exceeding 5mm in thickness. In such case, you need to gently scrape the frost off using an ice scraper rather than the metal or sharp hardware. Frost needs to be cleared off every 3 months or so, and if the drawers and access of foods are affected by frosting,

make sure to remove the frost in a timely manner.

- **FOLLOW THE FOLLOWING STEPS TO DEFROST**

- 1. Take out the frozen foods, shut off the mains power supply, open the fridge freezer door, and gently remove the frosts from the inner wall with an ice scraper. To speed up the thawing process, you are suggested to place a bowl of hot water inside the fridge freezer, and when the solid ice frosts become loose, use an ice scraper to scrape them off and then take them out.

- 2. After defrosting, clean the fridge freezer inside, and switch on the power supply.

- **NOTE:** When the appliance is not in use for long periods, disconnect from the electricity supply, empty all foods and clean the appliance, leaving the door ajar to prevent unpleasant smells.

- **SAFETY-CHECK AFTER MAINTENANCE**

- Is the power cord broken or damaged?

- Is the power plug firmly inserted into the socket?

- Is the power plug abnormally overheated.

- The appliance shall be disconnected from its power source during service and when replacing parts and, if that the removal of the plug is foreseen, it shall be clearly indicated that the removal of the plug has to be such that an operator can check from any of the points to which he has access that the plug remains removed. This refrigeration appliance is not intended to be used as a built-in appliance.

- **NOTE:** Electric shock and fire accident may be caused in case the power cord and plug is damaged or stained by dust. If any abnormality, please unplug the power plug and get in contact with the vendor.

TROUBLESHOOTING

Fault	Checks	Solutions
No operation.	Is power switched off. Are breakers and fuses tripped or blown. No electricity power cut.	Switch on.
Abnormal noise.	Is fridge freezer stable. Does fridge freezer touch the wall.	Adjusting fridge freezer's adjustable feet. Pull away from wall.
Poor refrigerating efficiency.	Hot food or overloading. Door closing. Is the fridge freezer in direct sunlight or close to central heating. Is the fridge freezer well ventilated. Check temperature settings	Allow food to cool and do not overload compartments. Check the door closing times and seal. Move appliance to a cooler area. Clear vents to maintain good ventilation. Set the appropriate temperature.
Peculiar smell in fridge freezer.	Spoiled food. Fridge freezer requires cleaning.	Remove offending articles. Clean fridge freezer.

Environment Protection and Waste Protection and Electrical Equipment Regulations (WEEE)

Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of it in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. Under the Waste Batteries and Accumulators Regulations 2009, Dellonda would like to inform the user that this product contains one or more batteries. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.