

# 3W LED & 3W COB LED TORCH/INSPECTION LIGHT

MODEL NO: LED069

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



instruction manual

1. SAFETY

- □ WARNING! DO NOT mix new and used batteries, nor mix different types nor mix from different manufacturers.
- □ WARNING! Remove the batteries when unused for a period of time to prevent battery leakage in the device.
- **DO NOT** shine directly into your, another person's or an animal's eyes. Take care when extending the body of the torch to operate the inspection lamp, that it is facing away from your eyes.
- **DO NOT** allow children to use the light.

#### 2. INTRODUCTION

Twin function light, features a powerful 3W LED directional torch and, by extending the body of the torch, an automatic on/off 3W COB LED inspection lamp. A strong magnet in the base allows for hands-free use. Powered by 4 x AAA batteries (not included).

# 3. SPECIFICATION

Model No:	LED069
Battery:	4 x AAA (not included)
LED Type:	3W COB + 3W LED
Lumen Output:	Side/Top; 150/50lm
Maximum Length:	220mm
Minimum Length:	165mm
Operating Time:	Side/Top: 5/8hr



## 4. FEATURES



# 5. OPERATION

5.1. FIT BATTERIES:

Unscrew magnetic end cap. Unlock battery compartment cap. Insert 4x AAA batteries (observe polarity). Refit caps.

5.2. **OPERATION:** see diagram above.

## 6. MAINTENANCE

6.1. Clean with a moist cloth, **DO NOT** use solvents.

© Jack Sealey Limited Original Language Version LED069 Issue:1 22/08/25



#### **WEEE REGULATIONS**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.





### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note**: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk

© Jack Sealey Limited Original Language Version LED069 Issue:1 22/08/25

7. ASSEMBL
------------

8. OPERATION

9. MAINTENANCE

| Issue: 16/04/18