



| Item | Part No. | Description |
|------|------------|------------------------------------|
| 1 | BSCU40A-01 | Bottom Panel |
| 2 | BSCU40A-02 | Block for Output Terminals |
| 3 | BSCU40A-03 | Block for Fuse (Fuse Included) |
| 4 | BSCU40A-04 | Back Panel |
| 5 | BSCU40A-05 | Internal Cap for Output Terminals |
| 6 | BSCU40A-06 | Self-Tapping Screw ST3x20 |
| 7 | BSCU40A-07 | Internal Board for Output Surface |
| 8 | BSCU40A-08 | Self-Tapping Screw ST3x6 |
| 9 | BSCU40A-09 | Screw M3x8 |
| 10 | BSCU40A-10 | Flat-Head Self-Tapping Screw ST3x8 |
| 11 | BSCU40A-11 | Top Cover |
| 12 | BSCU40A-12 | LED PCB Cover |
| 14 | BSCU40A-14 | Self-Tapping Screw ST3x12 |

| Item | Part No. | Description |
|------|------------|--|
| 15 | BSCU40A-15 | Front Panel |
| 16 | BSCU40A-16 | AC Input Socket |
| 17 | BSCU40A-17 | On-Off Switch |
| 18 | BSCU40A-18 | Cooling Fan |
| 19 | BSCU40A-19 | Galvanised Self-Tapping Screw ST3x25 |
| 20 | BSCU40A-20 | PCB Assembly |
| 21 | BSCU40A-21 | Galvanised Flat-Head Screw M3x8 |
| 22 | BSCU40A-22 | Plug |
| 23 | BSCU40A-23 | Output Clamp & Eyelet Cables with EC5 Connection |
| 24 | BSCU40A-24 | Temperature Sensor Cable |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.